


# Quick Start Guide



Grind & Brew Unit



Lid



Coffee Filter



Measuring Spoon



Grind Basket



Coffee Carafe

## How to Use:

Before brewing coffee for the first time, brew a full, 4-cup carafe of hot water with NO coffee beans or grounds. This will prime the Coffee Maker and clean out any dust that may have accumulated before use.




### STEP 1

Open water tank lid. Fill tank with desired amount of water.




### STEP 2

Place coffee carafe on warming plate.




### STEP 3

Ensure coffee filter is snapped into place.



### STEP 4

Put desired amount of beans or grounds into the grind basket.



### STEP 5

Close the lid.



### STEP 6

Use control dial to select corresponding setting.




### STEP 7

Press START. Coffee will be ready when Coffee Maker beeps three times and blue light stops flashing.



## Before First Use:

1. Read all instructions, including the User Guide, and follow them carefully.
2. Remove all packing materials and stickers from the inside and outside of the Coffee Maker. Gently wipe down exterior with a damp cloth or paper towel. **Warning:** Never immerse the Coffee Maker, its base, cord, or plug in water or any other liquids. The electrical connections must never come into contact with water or any other liquids.
3. Remove the grind basket and coffee filter using the instructions on the back of this page.
4. Wash all removable parts, except for the lid, with a sponge and warm, soapy water. Rinse lid with water. Dry completely.
5. Reassemble the grind basket, filter and lid using the instructions on the back of this page.




## Settings:

1. **Beans (3-4 Scoops)\*:** Use the control dial to select this setting when using whole coffee beans. May be used with 3-4 scoops to make 3-4 cups of coffee.
2. **Beans (1-2 Scoops):** Use the control dial to select this setting when using whole coffee beans. May be used with 1-2 scoops to make 1-2 cups of coffee.
3. **Grounds:** Use the control dial to select this setting when using ground coffee beans. May be used with 1-4 scoops to make 1-4 cups of coffee.

\*The 3-4 Scoop setting grinds slightly longer than the 1-2 Scoop setting, ensuring that your coffee grinds to the perfect coarseness every time.


## How to Remove the Grind Basket:

1. Press the lid release button and pull lid up to remove. (Figure 1.)
2. Twist the grind basket to the right and lift to remove. (Figure 2.)



## How to Reassemble the Grind Basket:

1. Position the grind basket over the grind basket holder on a 45 degree angle with the blade portion positioned in the back.
2. Push the basket into the grind basket holder. turn to the left to lock into place. (Figure 3.)




## How to Remove the Filter:

1. Remove coffee filter by using the coffee filter's handle to lift up and unsnap. (Figure 4.)

## How to Reassemble the Filter:

1. Insert the coffee filter by positioning the coffee filter's handle toward the front of the Coffee Maker.
2. Use the coffee filter's handle to place coffee filter into the back of the grind basket.
3. Push down to snap into place. (See Figure 5.)



## How to Close the Lid:

1. Guide the water pump spout into the hole on the right of the grind basket. (See Figure 6.)
2. Hold the lid release button and push down until the lid is securely in place.



## Cleaning and Maintenance:

After every use, allow Grind & Brew to cool completely before cleaning.

- Remove lid, grind basket and filter using the instructions on this Quick Start Guide.
- Wash all removable parts, except for the lid, with a sponge and warm, soapy water. Rinse lid. Dry completely.
- Rinse or wash coffee carafe after every use.
- Wipe down Coffee Maker's housing and warming plate with a damp cloth or paper towel as necessary.
- Descale Grind & Brew regularly using the instructions on page 9 in the user guide.

**Need Help?** Monday - Friday, 9 am to 5 pm

 (888) 315-6553

 [customerservice@chefman.com](mailto:customerservice@chefman.com)